

# Quick Start Guide

Sheet 17

## Window Cleaning Guide

---

Dear valued customer,

Please find enclosed your complimentary micro fiber towel for cleaning your laser micrometer windows. When not in use, please return to this bag or other dust-free enclosure to ensure the cloth gathers no contaminants, which could damage windows upon subsequent use.

Clean windows are critical to ensure the highest measurement accuracy. If the scanner is powered, any specks of dirt should "glow" under illumination of the laser. Any loose dirt should be blown off of the windows. If loose dirt, especially metal, is wiped across the windows, permanent scratching may result. If lung-power is not adequate, try "canned air" or compressed air.

Use a non-ammonia solution or isopropyl alcohol for best "non streaking" results. Wipe each window in the lengthwise direction. Do NOT scrub or wipe from top to bottom. If your windows have difficulty to remove water spots, we recommend a product called *Krud Kutter* available at your local home store.

Thank you,

LaserLinc Technical Support Team

